



HDMI 2.0 and DisplayPort 1.2 to HDMI 2.0 optical converter, HDHF-4K

Description

A 4K video signal wall-plate converter, the HDHF-4K is designed compact enough to fit into an one (1) gang sized slot. Although the HDHF-4K is compact in size, it is brilliant enough to convert both DisplayPort 1.2 and HDMI 2.0 4K video signals to an Optical HDMI 2.0 video signal.

The HDHF-4K transmits the converted HDMI 2.0 optical signal up to 200m (656feet) over one (1) multi-mode fiber (OM3) without any data compression or latency. The optical HDMI 2.0 receiver, HDFX-500-Rx and HDFX-700-Rx, is used to recover optical HDMI 2.0 to electrical HDMI 2.0 signal.

HDHF-4K offers simple and easy installation on the wall or boom system, as it removes any additional copper cable between faceplate and stand-alone converters. With its selection-switch, users can easily choose between either DisplayPort 1.2 or HDMI 2.0 4K signals to get converted and transmitted.

Specification

- Supports both DisplayPort 1.2 and HDMI 2.0 4K signals
- Supports up to 4K (4096x2160) at 60Hz, (RGB & YcbCr : 4 : 4 : 4)
- Transmits converted optical signal up to 200m (656ft) over
- LC terminated 1 core multi-mode fiber (OM3)
- Operated via DIP switch to select DisplayPort 1.2 or HDMI 2.0 for conversion and transmission.
- Equipped with three (3) LEDs for power detection and HDMI and DisplayPort signal selection.

Applications


- Surgical room
- Radiology
- Control room

HDMI 2.0 and DisplayPort 1.2 to HDMI 2.0 optical converter, HDHF-4K

Technical Features

| Resolution | Up to WQUXGA(4096x2160) at 60Hz for HDMI and DisplayPort input |
|--------------------------|---|
| Maximum distance | 200m (656feet) @WUXGA, 60Hz |
| Cable | LC terminated 1 core multi-mode fiber (62.5um) |
| Power supplying | 8~15V |
| LED Indicators | Power (Green), Video input status (Amber) |
| Power consumption | < 0.5W |
| Operating temperature | 0 ~ 50 ℃ |
| Operating humidity | 10~85% RH |

Dimension



One (1) Optical Fiber


Up to 200m at 4K

o B Up to 2M Copper Cable

Ì

HDHF-4K

HDMI Display



Connection Diagram

DisplayPort 1.2 / HDMI 2.0 Source

DisplayPort and HDM 3m Cable

CIS

www.opticis.com

Opticis Co., Ltd. 3F, 305, Sanseong-daero, Sujeong-gu, Seongnam-si, Gyeonggi-do, Republic of Korea 13354 Tel: +82 (31) 719-8033 Fax: +82 (31) 719-8032 tosales@opticis.com



All contents are subject to be changed without prior notice.